

Packing glider

It is important to correctly pack your glider as this prolongs its lifespan. We recommend that you fold the glider like a harmonica, neatly aligning the profiles with the leading edge reinforcements side by side. The wing should then be folded in three parts or two folds. The wing should be packed as loosely as possible. While packing be careful not to trap any grasshoppers inside your canopy as they will tear the canopy cloth. This technique will make your glider last longer and ensure its best performance.

Into the Drift Compression bag



Step 1 Open your compression bag (CB)



Step 2 put your glider to the middle of CB in "harmonica" style with leading edge's ribs one on each other



Step 3 Put the risers in the bag intended for them



Step 4 Start fastening the straps



Step 5 Fold the wing in the middle so that the colored markings at the bottom and top fits together



Step 6 Fold the wing in half again



Step 7 Zip it around and put into your backpack